

## Embout XZN pour Alternateur - M10 x 1/2"

For use on Bosch alternators with free wheel pulleys. For use on Audi, BMW, Ford, Skoda, Mercedes-Benz and Volkswagen. This two piece tool is ideal for dismantling and assembling the free wheel pulley whilst changing the alternator or pulley. The pulley shaft is held in place with the M10 spline bit on 1/2"D socket whilst the nut is undone using the 33 teeth union nut with 17mm spanner.



### Additional Information

- Convient pour les alternateurs Bosch avec des poulies séparées
- Convient pour Audi, BMW, Ford, Skoda, Mercedes-Benz et Volkswagen.
- Entraînement en 1/2"
- Ce jeu de 2 pcs est idéal pour démonter et réassembler les poulies
- La tige de la poulie est maintenue en place à l'aide de l'embout XZN en M10 bloqué sur une douille en 1/2" tandis que la douille à 33 dents est dévissée avec une clé de 17mm

<http://lasertools.co.uk/product/3307>