

## Kit de pose et dépose de silent bloc arrière avant sur

Part of a range of vehicle specific tools, for the removal and fitting of bushes and ball joints, without having to remove suspension legs, subframes, wishbones, trailing arms etc from the vehicle. Designed to be used in-situ, although many can also be used in a workshop press if circumstances require.



### Additional Information

- Application: Land Rover Discovery 3 et Range Rover Sport
- Peut être utilisé sur le véhicule - gain de temps
- A utiliser sur le silent bloc code constructeur RBX500291
- Fabriqué à Sheffield
- 

<http://lasertools.co.uk/product/6180>