



Kit de pose et dépose de silent Bloc sur le triangle avant

Part of a range of vehicle specific tools, for the removal and fitting of bushes and ball joints, without having to remove suspension legs, subframes, wishbones, trailing arms etc from the vehicle. Designed to be used in-situ, although many can also be used in a workshop press if circumstances require.



Additional Information

- Cet outil permet la pose et dépose de silent Bloc sur le triangle avant - Land Rover
- Equivalent au code constructeur 204-536
- Permet la pose et la dépose avec un minimum de désassemblage sur le véhicule.
- Applications : Discovery 3 & 4 (à partir de 2004), Range Rover Sport (à partir de 2005)

- A utiliser avec la ref 6180 pour le silent bloc arrière sur le triangle. Veillez à bien graisser la tige filetée et l'écrou de butée. Outil fabriqué à Sheffield

<http://lasertools.co.uk/product/6355>

