

## Brake Drum Wear Gauge

A multi functional tool that can be used to measure the wear limit on brake drums or measure the diameter of the drum and then set the shoe position prior to drum re-fitting.



### Additional Information

- Drum size range: 160mm - 400mm.
- Metric and Imperial scale.
- 
- 
- 

<http://lasertools.co.uk/product/5502>



