



Extracteur de roulement de roue avant - Ford Transit à

This kit has been developed to remove the front wheel bearing housing from the front drive flange. The front bearings are integral of their outer housing and due to their design are rendered un-serviceable when separated from the drive flange. Specifically for Ford Transit front wheel bearings from 2000.



Additional Information

- Ce kit a été mis au point pour déposer le logement du roulement de roue avant de dessus la bride d'entraînement avant. Les roulements avant font partie intégrante de leur logement externe et en raison de leur conception deviennent inutilisables s'ils sont séparés de la bride d'entraînement
- Ce jeu d'outils permet de séparer l'ancien roulement et la bride d'entraînement pour permettre de remplacer le roulement sans avoir à remplacer la bride d'entraînement.
- Une fois que le logement extérieur du roulement a été retiré, la bague de roulement extérieure du roulement intérieur doit être enlevée. Pour cette tâche, un équipement supplémentaire est nécessaire (Ref 5738)
- Fabrication à Sheffield
- Produit protégé par Tool Connection

<http://lasertools.co.uk/product/5545>

Video available: <http://youtu.be/KChhq2fsEWM>

