

## **Slide Hammer Adaptor**

Slide hammer adaptor.



## **Additional Information**

- Slide hammer adaptor.
- For use with 5550 and 5545 when a slide hammer is required.
- External thread 1 1/2" x 16tpi.
- Internal thread 5/8 UNF.
- · Selected steel.

http://lasertools.co.uk/product/5703















