

Crankshaft Trigger Wheel Installer - for JLR

Trigger wheel installer required to install the crankshaft position sensor ring on certain Land Rover engines and install trigger wheel to rear crankshaft on certain Jaguar models.



Additional Information

- Land Rover applications: required to install the crankshaft position sensor ring on Discovery 3, Discovery 4 and Range Rover Sport when fitted with TDV6 engine.
- Jaguar applications: required to install the trigger wheel to the rear of the crankshaft on X200 S Type, X250 XF, X350 XJ and X351 XJ.
- Equivalent to OEM 303-1130.
- Overall diameter: 123.5mm.
- · Specifically requested to repair sensor wheel dropping off or cracking.

http://lasertools.co.uk/product/6831



ibuted by The Tool Connection Ltd.
on Road | Southam | Warwickshire | CV47 0DR
44 (0) 1926 815 000 F | +44 (0) 1926 815 888

LASER Kamasa Gunson Connect







