

## Steering Wheel Alignment Tool

This spring loaded steering wheel level is designed to clamp onto the steering wheel before undertaking tracking or front-end wheel alignment. Ideal for use after a carrying out a steering or front suspension repair or adjustment to ensure the steering wheel is centralised.



### Additional Information

- To ensure a level steering wheel during front wheel alignment.
- Spring loaded, allowing automatic centring and self retention.
- Fits steering wheels with an internal diameter range 170 - 250mm and 280 - 340mm.
- Features a spirit level to indicate the horizontal position.
- Useful for ADAS and other modern driver assistance systems. Ideal for bodyshops, garages and tyre fitting centres.

<http://lasertools.co.uk/product/8266>

